



ADVANCE PRODUCTS & SYSTEMS, LLC

P.O. Box 60399
Lafayette, Louisiana 70596-0399
Toll Free: (800) 315-6009
Phone: (337) 233-6116
Fax: (337) 232-3860
Email: sales@apsonline.com
www.apsonline.com
ISO 9001 Certified

NITE CAP INSTALLATION INSTRUCTIONS

Before installing the Nite Cap you must remove the Pipe plug (Item # 10 shown below)

Note: Foreman Nite Caps are not pressure holding devices. However venting caps/pipe caps are standard features on most Foreman Nite Caps and are used to relieve the pipe of any naturally occurring pressure buildup.

Insert the Foreman Nite Cap into the end of the pipe, tighten down on the bolt, which in turn compresses the plates which expands the rubber creating a seal.



Before removing the Foreman Nite Cap from the pipe unscrew the vent cap/pipe cap to relieve the pipe of any pressure buildup.

Item No.	Description	No. Required
1	Outer Disc	1
2	Inner Disc	1
3	Hex Nut	1
4	Rubber Gasket	1
5	Steel and Fiber Washers	1
6	Hex-Head Bolt	1
7	Retaining Ring	1
8	Pipe Cap	1
9	Pipe Nipple	1
10	Pipe Plug	1

